

# TexNov



## Pave-Tex Installation Guide

Pave-Tex is a textured acrylic coating that is easily applied with a roller. Use it to resurface your asphalt driveway, parking lots, playgrounds and tennis courts or any other asphalt surfaces requiring lasting protection.

For the project, you will need the following tools and products:



### Surface Cleaner

- 1 L can cover  $\pm 3,7 \text{ m}^2$  (0,25 gal. can cover  $\pm 40 \text{ pi}^2$ )\*
- 3,78 L can cover  $\pm 14 \text{ m}^2$  (1 gal. can cover  $\pm 150 \text{ pi}^2$ )\*
- 18,9 L can cover  $\pm 70 \text{ m}^2$  (5 gal. can cover  $\pm 755 \text{ pi}^2$ )\*

*\*Undiluted*



Trowel or  
putty knife



### Asphalt Crack Filler

- 8 kg can seal up to 1.6 m linear (65 feet)\*
- 15 kg can seal up to 3 m linear (121 feet)\*
- 20 kg can seal up to 4.1 m linear (162 feet)\*

*\*3/4" wide crack*



10mm roller



### Pave-Tex Textured Coating

- 10 kg can cover an area of  $11 \text{ m}^2$  (120  $\text{pi}^2$ )\*
- 18 kg can cover an area of  $20 \text{ m}^2$  (216  $\text{pi}^2$ )\*
- 25 kg can cover an area of  $28 \text{ m}^2$  (300  $\text{pi}^2$ )\*

*\*For two layers. May vary depending on the porosity of the asphalt.*

Several colors  
available!





## Step 1 – Surface Preparation

New asphalt surfaces must have aged at least 6 months before installing **Pave-Tex**. **No tar or bitumen-based sealant should be present on the surface.**

The surface to be covered must be clean, dry, of good quality, free of crust, grease, oil, and scaling. Traces of grass and vegetation must be removed before installation. Potholes or holes several inches wide must be repaired with cold asphalt and aged at least 15 days before installation.

## Step 2 – Surface Cleaning

Clean the entire asphalt surface to be covered with Texnov Surface Cleaner diluted 10:1. Rinse with a pressure washer.

For oil or automotive fluid stains, use Texnov Surface Cleaner diluted 1:1, with a stiff brush or broom. Rinse thoroughly and leave to dry for 18 hours.

During the entire installation time and the following 24 hours, the asphalt must be protected against rain and other possible damage.



## Step 3 – Sealing the cracks

Once the asphalt is clean and dry, fill the existing cracks with elastic crack filler.

Apply using a trowel or putty knife. Work the product well into the cracks and progress from one end of the joint to the other to fill it as much as possible. Level and smooth the surface.

For cracks more than 1" deep, fill the crack with sand up to 3/4" below the asphalt surface.

Leave it to dry for at least 18 hours before the installation of **Pave-Tex**.



## Step 4 – Application of Pave-Tex

Apply two coats of **Pave-Tex** using a brush or roller. When applying, penetrate the coating well into the porosities of the asphalt and apply it crosswise. Avoid puddles and excess thickness.

Drying time in normal conditions:

Dry to the touch: 1h

Ready for 2nd coat: 24h

Vehicles on the surface: 48h

**Pave-Tex** will never be stronger than the surface on which it will be installed. If the surface is in poor condition, adhesion will not take place.



# TexNov

839 Joseph-Louis-Mathieu  
Sherbrooke J1R 0X3

**1 877 316-6388**

[www.pave-tex.com](http://www.pave-tex.com)  
[info@texnov.com](mailto:info@texnov.com)

